

## Diameter Sensor

Standard

*Splice is actuated by how close the drive is to the materials core*



### **Advantages, Functions & Features**

- Standard on all machines
- Activation point is repeatable and adjustable

### **Functional Requirements**

- Position of moving arm and Splice Imminent Flag can be adjusted to trigger at different roll diameters